


# StoryWalk®Solutions


## ALUMINUM FRAME with ALUMINUM POST-ANGLED

- •Designed for an 18"H x 24"W page, with a viewable area of 17"H x 23"W
- •45 Degree display angle
- •Standard post length of 60" for in-ground installation
  - •Longer post lengths available
  - •Surface mount aluminum posts available
- •Removable bottom rail for easy page insertion
- •Two sheets of acrylic protect the laminated page
- •3 Year Warranty on the powder-coated aluminum frame and post.
- •Made in the USA

28-32" FROM GRADE

SIGN PANEL MOUNTS





### Assembly Instructions:

1. Attach the frame to the post plate using the provided hardware and allen driver. You will need a 7/16" socket wrench to install the nylock nut. DO NOT use power tools as the stainless hardware may gall and seize.

- 2. Remove the 2 screws from the bottom frame rail with the provided allen driver.
- 3. Insert the acrylic sheets and replace the bottom rail.

#### Page Installation Instructions - First time

- 1. Remove the bottom frame rail using the provided allen driver
- 2. Remove the blue masking from both sides of the acrylic sheets.
- 3. Place your page and optional colored backer between the sheets of acrylic.
- 4. Slide the sheets into the frame bottom.
- 5. Replace the bottom rail.

Moisture Issue? Add 2 or 3 Clip Spacers to the bottom of your page to minimize water from creeping up between the acrylic sheets. It creates a larger gap; therefore, moisture will not be drawn between the sheets as easily. Clip spacers are small, plastic paper clips that are sold under the brand Plastiklips LP-0200.

#### Cleaning Instructions:

- •Use a soft cloth and a diluted soap & water solution to wash the display.
- •Dry the display with a soft cloth.
- •DO NOT USE ammonia cleaners (Windex) or paper towels as they may damage the acrylic.